



The Installation of Adjustable Angle Light Pole Adaptor



Threading inside the Pole Adaptor




3) 转接件装配好后，
电源输入线只需穿过
穿线软管。

3)After assembling the pole
adaptor, the power input line
can easily go through the flexible
pipe.

Angle Adjustment

4) When adjusting the angle, just loosening the screw, and adjusting the angle you want. Tightening the screw after that. Angle adjusting range: $-90^{\circ} \sim +90^{\circ}$, adjusting every 2.5°



4) 需调节角度时只需松开此处螺丝，
调整到所需要的角度再拧紧螺钉，
范围可调。 $-90^{\circ} \sim +90^{\circ}$ ，
每 2.5° 调节一次